

FIG. 1




FIG. 2

Palm OS
Shunt Calibration
1. Read Current [A] Present Calibration [%]
2. Enter measured battery current[A]
3. Calc. Calibration [%]
Calibrate Clear Calib. Close
0 0

FIG. 3




FIG. 4




FIG. 5